

The Linux SCSI programming HOWTO

Table of Contents

<u>The Linux SCSI programming HOWTO</u>	1
<u>Heiko Eißfeldt heiko@colossus.escape.de</u>	1
<u>1.What's New?</u>	1
<u>2.Introduction</u>	1
<u>3.What Is The Generic SCSI Interface?</u>	1
<u>4.What Are The Requirements To Use It?</u>	1
<u>5.Programmers Guide</u>	1
<u>6.Overview Of Device Programming</u>	1
<u>7.Opening The Device</u>	1
<u>8.The Header Structure</u>	2
<u>9.Inquiry Command Example</u>	2
<u>10.The Sense Buffer</u>	2
<u>11.Example Using Sense Buffer</u>	2
<u>12.ioctl Functions</u>	2
<u>13.Driver Defaults</u>	2
<u>14.Obtaining The Scsi Specifications</u>	2
<u>15.Related Information Sources</u>	2
<u>16.Other useful stuff</u>	2
<u>17.Other SCSI Access Interfaces</u>	3
<u>18.Final Comments</u>	3
<u>19.Acknowledgments</u>	3
<u>Appendix</u>	3
<u>20.Appendix</u>	3
<u>21.Error handling</u>	3
<u>22.Additional sense codes and additional sense code qualifiers</u>	3
<u>23.A SCSI command code quick reference</u>	3
<u>24.Example programs</u>	3
<u>1.What's New?</u>	4
<u>2.Introduction</u>	4
<u>3.What Is The Generic SCSI Interface?</u>	4
<u>4.What Are The Requirements To Use It?</u>	5
<u>4.1 Kernel Configuration</u>	5
<u>4.2 Device Files</u>	5
<u>4.3 Device Mapping</u>	6
<u>Dynamically insert and remove SCSI devices</u>	6
<u>5.Programmers Guide</u>	7
<u>6.Overview Of Device Programming</u>	7
<u>7.Opening The Device</u>	9
<u>8.The Header Structure</u>	9
<u>9.Inquiry Command Example</u>	12
<u>10.The Sense Buffer</u>	15
<u>11.Example Using Sense Buffer</u>	16
<u>12.ioctl Functions</u>	17
<u>13.Driver Defaults</u>	18
<u>13.1 Transfer Lengths</u>	18
<u>13.2 Timeout And Retry Values</u>	18
<u>14.Obtaining The Scsi Specifications</u>	18

Table of Contents

15.Related Information Sources	19
15.1 HOWTOs and FAQs	19
15.2 Mailing list	19
15.3 Example code	20
16.Other useful stuff	20
16.1 Device driver writer helpers	20
16.2 Utilities	21
17.Other SCSI Access Interfaces	21
18.Final Comments	21
19.Acknowledgments	22
20.Appendix	22
21.Error handling	22
21.1 Error status decoding	23
21.2 Status codes	23
21.3 SCSI Sense Keys	25
21.4 Host codes	27
21.5 Driver codes	27
22.Additional sense codes and additional sense code qualifiers	28
22.1 ASC and ASCQ in lexical order	28
22.2 ASC and ASCQ in numerical order	32
23.A SCSI command code quick reference	38
24.Example programs	42

The Linux SCSI programming HOWTO

Heiko Eiβfeldt heiko@colossus.escape.de

v1.5, 7 May 1996

This document deals with programming the Linux generic SCSI interface.

1. What's New?

2. Introduction

3. What Is The Generic SCSI Interface?

4. What Are The Requirements To Use It?

- [4.1 Kernel Configuration](#)
- [4.2 Device Files](#)
- [4.3 Device Mapping](#)

5. Programmers Guide

6. Overview Of Device Programming

7. Opening The Device

8.The Header Structure

9.Inquiry Command Example

10.The Sense Buffer

11.Example Using Sense Buffer

12.ioctl Functions

13.Driver Defaults

- [13.1 Transfer Lengths](#)
- [13.2 Timeout And Retry Values](#)

14.Obtaining The Scsi Specifications

15.Related Information Sources

- [15.1 HOWTOs and FAQs](#)
- [15.2 Mailing list](#)
- [15.3 Example code](#)

16.Other useful stuff

- [16.1 Device driver writer helpers](#)
- [16.2 Utilities](#)

17. Other SCSI Access Interfaces

18. Final Comments

19. Acknowledgments

Appendix

20. Appendix

21. Error handling

- [21.1 Error status decoding](#)
- [21.2 Status codes](#)
- [21.3 SCSI Sense Keys](#)
- [21.4 Host codes](#)
- [21.5 Driver codes](#)

22. Additional sense codes and additional sense code qualifiers

- [22.1 ASC and ASCO in lexical order](#)
- [22.2 ASC and ASCO in numerical order](#)

23. A SCSI command code quick reference

24. Example programs

1. What's New?

Newer kernels have changed the interface a bit. This affects a section formerly entitled 'rescanning the devices'. Now it is possible to add/remove SCSI devices on the fly.

Since kernel 1.3.98 some important header files have been moved/split (`sg.h` and `scsi.h`).

Some stupid bugs have been replaced by newer ones.

2. Introduction

This document is a guide to the installation and programming of the Linux generic SCSI interface.

It covers kernel prerequisites, device mappings, and basic interaction with devices. Some simple C programming examples are included. General knowledge of the SCSI command set is required; for more information on the SCSI standard and related information, see the appendix to this document.

Note the plain text version of this document lacks cross references (they show up as ``").

3. What Is The Generic SCSI Interface?

The generic SCSI interface has been implemented to provide general SCSI access to (possibly exotic) pieces of SCSI hardware. It was developed by Lawrence Foard (`entropy@world.std.com`) and sponsored by Killy Corporation (see the comments in `scsi/sg.h`).

The interface makes special device handling possible from user level applications (i.e. outside the kernel). Thus, kernel driver development, which is more risky and difficult to debug, is not necessary.

However, if you don't program the driver properly it is possible to hang the SCSI bus, the driver, or the kernel. Therefore, it is important to properly program the generic driver and to first back up all files to avoid losing data. Another useful thing to do before running your programs is to issue a `sync` command to ensure that any buffers are flushed to disk, minimizing data loss if the system hangs.

Another advantage of the generic driver is that as long as the interface itself does not change, all applications are independent of new kernel development. In comparison, other low-level kernel drivers have to be synchronized with other internal kernel changes.

Typically, the generic driver is used to communicate with new SCSI hardware devices that require special user applications to be written to take advantage of their features (e.g. scanners, printers, CD-ROM jukeboxes). The generic interface allows these to be written quickly.

4.3 Device Mapping

These device files are dynamically mapped to SCSI id/LUNs on your SCSI bus (LUN = logical unit). The mapping allocates devices consecutively for each LUN of each device on each SCSI bus found at time of the SCSI scan, beginning at the lower LUNs/ids/buses. It starts with the first SCSI controller and continues without interruption with all following controllers. This is currently done in the initialisation of the SCSI driver.

For example, assuming you had three SCSI devices hooked up with ids 1, 3, and 5 on the first SCSI bus (each having one LUN), then the following mapping would be in effect:

```
/dev/sga -> SCSI id 1
/dev/sgb -> SCSI id 3
/dev/sgc -> SCSI id 5
```

If you now add a new device with id 4, then the mapping (after the next rescan) will be:

```
/dev/sga -> SCSI id 1
/dev/sgb -> SCSI id 3
/dev/sgc -> SCSI id 4
/dev/sgd -> SCSI id 5
```

Notice the change for id 5 — the corresponding device is no longer mapped to `/dev/sgc` but is now under `/dev/sgd`.

Luckily newer kernels allow for changing this order.

Dynamically insert and remove SCSI devices

If a newer kernel and the `/proc` file system is running, a non-busy device can be removed and installed 'on the fly'.

To remove a SCSI device:

```
echo "scsi remove-single-device a b c d" > /proc/scsi/scsi
```

and similar, to add a SCSI device, do

```
echo "scsi add-single-device a b c d" > /proc/scsi/scsi
```

where

The Linux SCSI programming HOWTO

```
a == hostadapter id (first one being 0)
b == SCSI channel on hostadapter (first one being 0)
c == ID
d == LUN (first one being 0)
```

So in order to swap the `/dev/sgc` and `/dev/sgd` mappings from the previous example, we could do

```
echo "scsi remove-single-device 0 0 4 0" > /proc/scsi/scsi
echo "scsi remove-single-device 0 0 5 0" > /proc/scsi/scsi
echo "scsi add-single-device 0 0 5 0" > /proc/scsi/scsi
echo "scsi add-single-device 0 0 4 0" > /proc/scsi/scsi
```

since generic devices are mapped in the order of their insertion.

When adding more devices to the scsi bus keep in mind there are limited spare entries for new devices. The memory has been allocated at boot time and has room for 2 more devices.

5. [Programmers Guide](#)

The following sections are for programmers who want to use the generic SCSI interface in their own applications. An example will be given showing how to access a SCSI device with the INQUIRY and the TESTUNITREADY commands.

When using these code examples, note the following:

- the location of the header files `sg.h` and `scsi.h` has changed in kernel version 1.3.98. Now these files are located at `/usr/src/linux/include/scsi`, which is hopefully linked to `/usr/include/scsi`. Previously they were in `/usr/src/linux/drivers/scsi`. We assume a newer kernel in the following text.
- the generic SCSI interface was extended in kernel version 1.1.68; the examples require at least this version. But please avoid kernel version 1.1.77 up to 1.1.89 and 1.3.52 upto 1.3.56 since they had a broken generic scsi interface.
- the constant `DEVICE` in the header section describing the accessed device should be set according to your available devices (see section [sec-header](#)).

6. [Overview Of Device Programming](#)

The header file `include/scsi/sg.h` contains a description of the interface (this is based on kernel version 1.3.98):

The Linux SCSI programming HOWTO

```
struct sg_header
{
    int pack_len;
                                /* length of incoming packet (including header) */
    int reply_len; /* maximum length of expected reply */
    int pack_id;   /* id number of packet */
    int result;    /* 0=ok, otherwise refer to errno codes */
    unsigned int twelve_byte:1;
                                /* Force 12 byte command length for group 6 & 7 commands */
    unsigned int other_flags:31; /* for future use */
    unsigned char sense_buffer[16]; /* used only by reads */
    /* command follows then data for command */
};
```

This structure describes how a SCSI command is to be processed and has room to hold the results of the execution of the command. The individual structure components will be discussed later in section [sec-header](#).

The general way of exchanging data with the generic driver is as follows: to send a command to an opened generic device, `write()` a block containing these three parts to it:

```
struct sg_header
SCSI command
data to be sent with the command
```

To obtain the result of a command, `read()` a block with this (similar) block structure:

```
struct sg_header
data coming from the device
```

This is a general overview of the process. The following sections describe each of the steps in more detail.

NOTE: Up to recent kernel versions, it is necessary to block the SIGINT signal between the `write()` and the corresponding `read()` call (i.e. via `sigprocmask()`). A return after the `write()` part without any `read()` to fetch the results will block on subsequent accesses. This signal blocking has not yet been included in the example code. So better do not issue SIGINT (a la ^C) when running these examples.

7. Opening The Device

A generic device has to be opened for read and write access:

```
int fd = open (device_name, O_RDWR);
```

(This is the case even for a read-only hardware device such as a cdrom drive).

We have to perform a `write` to send the command and a `read` to get back any results. In the case of an error the return code is negative (see section [sec-errorhandling](#) for a complete list).

8. The Header Structure

The header structure `struct sg_header` serves as a controlling layer between the application and the kernel driver. We now discuss its components in detail.

int pack_len

defines the size of the block written to the driver. This is defined within the kernel for internal use.

int reply_len

defines the size of the block to be accepted at reply. This is defined from the application side.

int pack_id

This field helps to assign replies to requests. The application can supply a unique id for each request. Suppose you have written several commands (say 4) to one device. They may work in parallel, one being the fastest. When getting replies via 4 reads, the replies do not have to have the order of the requests. To identify the correct reply for a given request one can use the `pack_id` field. Typically its value is incremented after each request (and wraps eventually). The maximum amount of outstanding requests is limited by the kernel to `SG_MAX_QUEUE` (eg 4).

int result

the result code of a `read` or `write` call. This is (sometimes) defined from the generic driver (kernel) side. It is safe to set it to null before the `write` call. These codes are defined in `errno.h` (0 meaning no error).

unsigned int twelve_byte:1

This field is necessary only when using non-standard vendor specific commands (in the range 0xc0 – 0xff). When these commands have a command length of 12 bytes instead of 10, this field has to be set to one before the write call. Other command lengths are not supported. This is defined from the application side.

unsigned char sense_buffer[16]

This buffer is set after a command is completed (after a `read()` call) and contains the SCSI sense code. Some command results have to be read from here (e.g. for TESTUNITREADY). Usually it contains just zero bytes. The value in this field is set by the generic driver (kernel) side.

The following example function interfaces directly with the generic kernel driver. It defines the header structure, sends the command via `write`, gets the result via `read` and does some (limited) error checking. The sense buffer data is available in the output buffer (unless a NULL pointer has been given, in which case it's in the input buffer). We will use it in the examples which follow.

Note: Set the value of `DEVICE` to your device descriptor.

```
#define DEVICE "/dev/sgc"

/* Example program to demonstrate the generic SCSI interface */
#include <stdio.h>
#include <unistd.h>
#include <string.h>
#include <fcntl.h>
#include <errno.h>
#include <scsi/sg.h>

#define SCSI_OFF sizeof(struct sg_header)
static unsigned char cmd[SCSI_OFF + 18]; /* SCSI command buffer */
int fd; /* SCSI device/file descriptor */

/* process a complete SCSI cmd. Use the generic SCSI interface. */
static int handle_SCSI_cmd(unsigned cmd_len, /* command length */
                          unsigned in_size, /* input data size */
                          unsigned char *i_buff, /* input buffer */
                          unsigned out_size, /* output data size */
                          unsigned char *o_buff /* output buffer */
                          )
{
    int status = 0;
    struct sg_header *sg_hd;

    /* safety checks */
    if (!cmd_len) return -1; /* need a cmd_len != 0 */
    if (!i_buff) return -1; /* need an input buffer != NULL */
#ifdef SG_BIG_BUFFER
    if (SCSI_OFF + cmd_len + in_size > SG_BIG_BUFFER) return -1;
#endif
}
```

The Linux SCSI programming HOWTO

```
    if (SCSI_OFF + out_size > SG_BIG_BUFF) return -1;
#else
    if (SCSI_OFF + cmd_len + in_size > 4096) return -1;
    if (SCSI_OFF + out_size > 4096) return -1;
#endif

    if (!o_buff) out_size = 0;          /* no output buffer, no output size */

    /* generic SCSI device header construction */
    sg_hd = (struct sg_header *) i_buff;
    sg_hd->reply_len = SCSI_OFF + out_size;
    sg_hd->twelve_byte = cmd_len == 12;
    sg_hd->result = 0;
#if 0
    sg_hd->pack_len = SCSI_OFF + cmd_len + in_size; /* not necessary */
    sg_hd->pack_id; /* not used */
    sg_hd->other_flags; /* not used */
#endif

    /* send command */
    status = write( fd, i_buff, SCSI_OFF + cmd_len + in_size );
    if ( status < 0 || status != SCSI_OFF + cmd_len + in_size ||
        sg_hd->result ) {
        /* some error happened */
        fprintf( stderr, "write(generic) result = 0x%x cmd = 0x%x\n",
                sg_hd->result, i_buff[SCSI_OFF] );
        perror("");
        return status;
    }

    if (!o_buff) o_buff = i_buff;      /* buffer pointer check */

    /* retrieve result */
    status = read( fd, o_buff, SCSI_OFF + out_size);
    if ( status < 0 || status != SCSI_OFF + out_size || sg_hd->result ) {
        /* some error happened */
        fprintf( stderr, "read(generic) status = 0x%x, result = 0x%x, "
                "cmd = 0x%x\n",
                status, sg_hd->result, o_buff[SCSI_OFF] );
        fprintf( stderr, "read(generic) sense "
                "%x %x %x\n",
                sg_hd->sense_buffer[0], sg_hd->sense_buffer[1],
                sg_hd->sense_buffer[2], sg_hd->sense_buffer[3],
                sg_hd->sense_buffer[4], sg_hd->sense_buffer[5],
                sg_hd->sense_buffer[6], sg_hd->sense_buffer[7],
                sg_hd->sense_buffer[8], sg_hd->sense_buffer[9],
                sg_hd->sense_buffer[10], sg_hd->sense_buffer[11],
                sg_hd->sense_buffer[12], sg_hd->sense_buffer[13],
                sg_hd->sense_buffer[14], sg_hd->sense_buffer[15]);
        if (status < 0)
            perror("");
    }
    /* Look if we got what we expected to get */
    if (status == SCSI_OFF + out_size) status = 0; /* got them all */

    return status; /* 0 means no error */
}
```

While this may look somewhat complex at first appearance, most of the code is for error checking and reporting (which is useful even after the code is working).

The Linux SCSI programming HOWTO

Handle_SCSI_cmd has a generalized form for all SCSI commands types, falling into each of these categories:

Data Mode	Example Command
neither input nor output data	test unit ready
no input data, output data	inquiry, read
input data, no output data	mode select, write
input data, output data	mode sense

9. Inquiry Command Example

One of the most basic SCSI commands is the INQUIRY command, used to identify the type and make of the device. Here is the definition from the SCSI-2 specification (for details refer to the SCSI-2 standard).

Table 44: INQUIRY Command

Bit	7	6	5	4	3	2	1	0
0	Operation Code (12h)							
1	Logical Unit Number				Reserved			EVPD
2	Page Code							
3	Reserved							
4	Allocation Length							
5	Control							

The output data are as follows:

Table 45: Standard INQUIRY Data Format

Bit	7	6	5	4	3	2	1	0
0	Peripheral Qualifier				Peripheral Device Type			
1	RMB	Device-Type Modifier						
2	ISO Version			ECMA Version		ANSI-Approved Version		

The Linux SCSI programming HOWTO

3	AENC	TrmIOP	Reserved	Response Data Format	
4	Additional Length (n-4)				
5	Reserved				
6	Reserved				
7	RelAdr	WBus32	WBus16	Sync Linked Reserved CmdQue SftRe	
8	(MSB)	Vendor Identification			(LSB)
15					
16	(MSB)	Product Identification			(LSB)
31					
32	(MSB)	Product Revision Level			(LSB)
35					
36	Vendor Specific				
55					
56	Reserved				
95					
=====					
Vendor-Specific Parameters					
=====					
96	Vendor Specific				
n					
=====					

The next example uses the low-level function `handle_SCSI_cmd` to perform the Inquiry SCSI command.

We first append the command block to the generic header, then call `handle_SCSI_cmd`. Note that the output buffer size argument for the `handle_SCSI_cmd` call excludes the generic header size. After command completion the output buffer contains the requested data, unless an error occurred.

```
#define INQUIRY_CMD      0x12
#define INQUIRY_CMDLEN  6
#define INQUIRY_REPLY_LEN 96
#define INQUIRY_VENDOR  8      /* Offset in reply data to vendor name */

/* request vendor brand and model */
static unsigned char *Inquiry ( void )
{
    unsigned char Inqbuffer[ SCSI_OFF + INQUIRY_REPLY_LEN ];
    unsigned char cmdblk [ INQUIRY_CMDLEN ] =
        { INQUIRY_CMD, /* command */
          0, /* lun/reserved */
```

The Linux SCSI programming HOWTO

```
        0, /* page code */
        0, /* reserved */
INQUIRY_REPLY_LEN, /* allocation length */
        0 }; /* reserved/flag/link */

memcpy( cmd + SCSI_OFF, cmdblk, sizeof(cmdblk) );

/*
 * +-----+
 * | struct sg_header | <- cmd
 * +-----+
 * | copy of cmdblk   | <- cmd + SCSI_OFF
 * +-----+
 */

if (handle SCSI_cmd(sizeof(cmdblk), 0, cmd,
                    sizeof(Inqbuffer) - SCSI_OFF, Inqbuffer) ) {
    fprintf( stderr, "Inquiry failed\n" );
    exit(2);
}
return (Inqbuffer + SCSI_OFF);
}
```

The example above follows this structure. The Inquiry function copies its command block behind the generic header (given by SCSI_OFF). Input data is not present for this command. Handle SCSI_cmd will define the header structure. We can now implement the function main to complete this working example program.

```
void main( void )
{
    fd = open(DEVICE, O_RDWR);
    if (fd < 0) {
        fprintf( stderr, "Need read/write permissions for "DEVICE".\n" );
        exit(1);
    }

    /* print some fields of the Inquiry result */
    printf( "%s\n", Inquiry() + INQUIRY_VENDOR );
}
}
```

We first open the device, check for errors, and then call the higher level subroutine. Then we print the results in human readable format including the vendor, product, and revision.

Note: There is more information in the Inquiry result than this little program gives. You may want to extend the program to give device type, ANSI version etc. The device type is of special importance, since it determines the mandatory and optional command sets for this device. If you don't want to program it yourself, you may want to use the scsiinfo program from Eric Youngdale, which requests nearly all information about an SCSI device. Look at [tsx-11.mit.edu](http://tsx-11.mit.edu/pub/Linux/ALPHA/scsi) in `pub/Linux/ALPHA/scsi`.

10. The Sense Buffer

Commands with no output data can give status information via the sense buffer (which is part of the header structure). Sense data is available when the previous command has terminated with a CHECK CONDITION status. In this case the kernel automatically retrieves the sense data via a REQUEST SENSE command. Its structure is:

Bit	7	6	5	4	3	2	1	0
0	Valid	Error Code (70h or 71h)						
1	Segment Number							
2	Filemark	EOM	ILI	Reserved	Sense Key			
3	(MSB)							
6	Information							(LSB)
7	Additional Sense Length (n-7)							
8	(MSB)							
11	Command-Specific Information							(LSB)
12	Additional Sense Code							
13	Additional Sense Code Qualifier							
14	Field Replaceable Unit Code							
15	SKSV	Sense-Key Specific						
17								
18								
n	Additional Sense Bytes							

Note: The most useful fields are Sense Key (see section [sec-sensekeys](#)), Additional Sense Code and Additional Sense Code Qualifier (see section [sec-sensecodes](#)). The latter two are used combined as a pair.

11. Example Using Sense Buffer

Here we will use the TEST UNIT READY command to check whether media is loaded into our device. The header declarations and function `handle_SCSI_cmd` from the inquiry example will be needed as well.

Table 73: TEST UNIT READY Command

Bit	7	6	5	4	3	2	1	0
Byte								
0	Operation Code (00h)							
1	Logical Unit Number				Reserved			
2	Reserved							
3	Reserved							
4	Reserved							
5	Control							

Here is the function which implements it:

```
#define TESTUNITREADY_CMD 0
#define TESTUNITREADY_CMDLEN 6

#define ADD_SENSECODE 12
#define ADD_SC_QUALIFIER 13
#define NO_MEDIA_SC 0x3a
#define NO_MEDIA_SCQ 0x00

int TestForMedium ( void )
{
    /* request READY status */
    static unsigned char cmdblk [TESTUNITREADY_CMDLEN] = {
        TESTUNITREADY_CMD, /* command */
        0, /* lun/reserved */
        0, /* reserved */
        0, /* reserved */
        0, /* reserved */
        0}; /* control */

    memcpy( cmd + SCSI_OFF, cmdblk, sizeof(cmdblk) );

    /*
     * +-----+
     * | struct sg_header | <- cmd
     * +-----+
     */
}
```

The Linux SCSI programming HOWTO

```
 * | copy of cmdblk | <- cmd + SCSI_OFF
 * +-----+
 */

if (handle_SCSI_cmd(sizeof(cmdblk), 0, cmd,
                    0, NULL)) {
    fprintf (stderr, "Test unit ready failed\n");
    exit(2);
}

return
*((struct sg_header*)cmd)->sense_buffer +ADD_SENSECODE) !=
                                NO_MEDIA_SC ||
*((struct sg_header*)cmd)->sense_buffer +ADD_SC_QUALIFIER) !=
                                NO_MEDIA_SCQ;
}
```

Combined with this main function we can do the check.

```
void main( void )
{
    fd = open(DEVICE, O_RDWR);
    if (fd < 0) {
        fprintf( stderr, "Need read/write permissions for "DEVICE".\n" );
        exit(1);
    }

    /* look if medium is loaded */

    if (!TestForMedium()) {
        printf("device is unloaded\n");
    } else {
        printf("device is loaded\n");
    }
}
```

The file `generic_demo.c` from the appendix contains both examples.

12.ioctl Functions

There are two ioctl functions available:

- `ioctl(fd, SG_SET_TIMEOUT, &Timeout);` sets the timeout value to `Timeout * 10` milliseconds. `Timeout` has to be declared as `int`.
- `ioctl(fd, SG_GET_TIMEOUT, &Timeout);` gets the current timeout value. `Timeout` has to be declared as `int`.

13. [Driver Defaults](#)

13.1 Transfer Lengths

Currently (at least up to kernel version 1.1.68) input and output sizes have to be less than or equal than 4096 bytes unless the kernel has been compiled with `SG_BIG_BUFFER` defined, in which case it is limited to `SG_BIG_BUFFER` (e.g. 32768) bytes. These sizes include the generic header as well as the command block on input. `SG_BIG_BUFFER` can be safely increased upto (131072 - 512). To take advantage of this, a new kernel has to be compiled and booted, of course.

13.2 Timeout And Retry Values

The default timeout value is set to one minute (`Timeout = 6000`). It can be changed through an `ioctl` call (see section [sec-ioc1](#)). The default number of retries is one.

14. [Obtaining The Scsi Specifications](#)

There are standards entitled SCSI-1 and SCSI-2 (and possibly soon SCSI-3). The standards are mostly upward compatible.

The SCSI-1 standard is (in the author's opinion) mostly obsolete, and SCSI-2 is the most widely used. SCSI-3 is very new and very expensive. These standardized command sets specify mandatory and optional commands for SCSI manufacturers and should be preferred over the vendor specific command extensions which are not standardized and for which programming information is seldom available. Of course sometimes there is no alternative to these extensions.

Electronic copies of the latest drafts are available via anonymous ftp from:

- `ftp.cs.tulane.edu:pub/scsi`
- `ftp.symbios.com:/pub/standards`
- `ftp.cs.uni-sb.de:/pub/misc/doc/scsi`

(I got my SCSI specification from the Yggdrasil Linux CD-ROM in the directory `/usr/doc/scsi-2` and `/usr/doc/scsi-1`).

The SCSI FAQ also lists the following sources of printed information:

The SCSI specification: Available from:

The Linux SCSI programming HOWTO

15 Inverness Way East
Englewood Co 80112-5704
(800) 854-7179
SCSI-1: X3.131-1986
SCSI-2: X3.131-199x
SCSI-3 X3T9.2/91-010R4 Working Draft

(Global Engineering Documentation in Irvine, CA (714)261-1455??)

SCSI-1: Doc \# X3.131-1986 from ANSI, 1430 Broadway, NY, NY 10018

IN-DEPTH EXPLORATION OF SCSI can be obtained from
Solution Technology, Attn: SCSI Publications, POB 104, Boulder Creek,
CA 95006, (408)338-4285, FAX (408)338-4374

THE SCSI ENCYCLOPEDIA and the SCSI BENCH REFERENCE can be obtained from
ENDL Publishing, 14426 Black Walnut Ct., Saratoga, CA 95090,
(408)867-6642, FAX (408)867-2115

SCSI: UNDERSTANDING THE SMALL COMPUTER SYSTEM INTERFACE was published
by Prentice-Hall, ISBN 0-13-796855-8

15. [Related Information Sources](#)

15.1 HOWTOs and FAQs

The Linux **SCSI-HOWTO** by Drew Eckhardt covers all supported SCSI controllers as well as device specific questions. A lot of troubleshooting hints are given. It is available from [sunsite.unc.edu](http://sunsite.unc.edu/pub/Linux/docs/LDP) in [/pub/Linux/docs/LDP](http://pub/Linux/docs/LDP) and its mirror sites.

General questions about SCSI are answered in the **SCSI-FAQ** from the newsgroup Comp.Peripherals.Scsi (available on tsx-11 in pub/linux/ALPHA/scsi and mirror sites).

15.2 Mailing list

There is a **mailing list** for bug reports and questions regarding SCSI development under Linux. To join, send email to majordomo@vger.rutgers.edu with the line `subscribe linux-scsi` in the body of the message. Messages should be posted to linux-scsi@vger.rutgers.edu. Help text can be requested by sending the message line "help" to majordomo@vger.rutgers.edu.

15.3 Example code

sunsite.unc.edu: apps/graphics/hpscanpbm-0.3a.tar.gz

This package handles a HP scanjet scanner through the generic interface.

tsx-11.mit.edu: BETA/cdrom/private/mkisofs/cdwrite-1.3.tar.gz

The cdwrite package uses the generic interface to write a cd image to a cd writer.

sunsite.unc.edu: apps/sound/cds/cdda2wav.src.tar.gz*

A shameless plug for my own application, which copies audio cd tracks into wav files.

16. [Other useful stuff](#)

Things that may come in handy. I don't have no idea if there are newer or better versions around. Feedback is welcome.

16.1 Device driver writer helpers

These documents can be found at the sunsite.unc.edu ftp server and its mirrors.

/pub/Linux/docs/kernel/kernel-hackers-guide

The LDP kernel hackers guide. May be a bit outdated, but covers the most fundamental things.

/pub/Linux/docs/kernel/drivers.doc.z

This document covers writing character drivers.

/pub/Linux/docs/kernel/tutorial.doc.z

Tutorial on writing a character device driver with code.

/pub/Linux/docs/kernel/scsi.paper.tar.gz

A Latex document describing howto write a SCSI driver.

/pub/Linux/docs/hardware/DEVICES

A list of device majors and minors used by Linux.

16.2 Utilities

tsx-11.mit.edu: ALPHA/scsi/scsiinfo.tar.gz*

Program to query a scsi device for operating parameters, defect lists, etc. An X-based interface is available which requires you have Tk/Tcl/wish installed. With the X-based interface you can easily alter the settings on the drive.

tsx-11.mit.edu: ALPHA/kdebug

A gdb extension for kernel debugging.

17. [Other SCSI Access Interfaces](#)

In Linux there is also another SCSI access method via SCSI_IOCTL_SEND_COMMAND ioctl calls, which is deprecated. Special tools like 'scsiinfo' utilize it.

There are some other similar interfaces in use in the un*x world, but not available for Linux:

1. CAM (Common Access Method) developed by Future Domain and other SCSI vendors. Linux has little support for a SCSI CAM system yet (mainly for booting from hard disk). CAM even supports target mode, so one could disguise ones computer as a peripheral hardware device (e.g. for a small SCSI net).
2. ASPI (Advanced SCSI Programming Interface) developed by Adaptec. This is the de facto standard for MS-DOS machines.

There are other application interfaces from SCO(TM), NeXT(TM), Silicon Graphics(TM) and SUN(TM) as well.

18. [Final Comments](#)

The generic SCSI interface bridges the gap between user applications and specific devices. But rather than bloating a lot of programs with similar sets of low-level functions, it would be more desirable to have a shared library with a generalized set of low-level functions for a particular purpose. The main goal should be to have independent layers of interfaces. A good design would separate an application into low-level and hardware independent routines. The low-level routines could be put into a shared library and made available for all applications. Here, standardized interfaces should be followed as much as possible before making new ones.

By now you should know more than I do about the Linux generic SCSI interface. So you can start developing

powerful applications for the benefit of the global Linux community now...

19. Acknowledgments

Special thanks go to Jeff Tranter for proofreading and enhancing the text considerably as well as to Carlos Puchol for useful comments. Drew Eckhardt's and Eric Youngdale's help on my first (dumb) questions about the use of this interface has been appreciated.

20. Appendix

21. Error handling

The functions `open`, `ioctl`, `write` and `read` can report errors. In this case their return value is `-1` and the global variable `errno` is set to the error number. The `errno` values are defined in `/usr/include/errno.h`. Possible values are:

Function	Error	Description
open	ENXIO	not a valid device
	EACCES	access mode is not read/write (O_RDWR)
	EBUSY	device was requested for nonblocking access, but is busy now.
	ERESTARTSYS	this indicates an internal error. Try to make it reproducible and inform the SCSI channel (for details on bug reporting see Drew Eckhardts SCSI-HOWTO).
ioctl	ENXIO	not a valid device
read	EAGAIN	the device would block. Try again later.
	ERESTARTSYS	this indicates an internal error. Try to make it reproducible and inform the SCSI channel (for details on bug reporting see Drew Eckhardts SCSI-HOWTO).
write	EIO	the length is too small (smaller than the generic header struct). Caution: Currently there is no overlength checking.
	EAGAIN	the device would block. Try again later.
	ENOMEM	memory required for this request could not be allocated. Try later again unless you exceeded the maximum transfer size (see above)
select		none
close		none

For read/write positive return values indicate as usual the amount of bytes that have been successfully transferred. This should equal the amount you requested.

21.1 Error status decoding

Furthermore a detailed reporting is done via the kernels `hd_status` and the devices `sense_buffer` (see section [sec-sensebuff](#)) both from the generic header structure.

The meaning of `hd_status` can be found in `drivers/scsi/scsi.h`: This unsigned `int` is composed out of different parts:

```

    lsb |      ...      |      ...      | msb
=====|=====|=====|=====
status | sense key | host code | driver byte

```

These macros from `drivers/scsi/scsi.h` are available, but unfortunately cannot be easily used due to weird header file interdependencies. This has to be cleaned.

Macro	Description
<code>status_byte(hd_status)</code>	The SCSI device status. See section Status codes
<code>msg_byte(hd_status)</code>	From the device. See section SCSI sense keys
<code>host_byte(hd_status)</code>	From the kernel. See section Hostcodes
<code>driver_byte(hd_status)</code>	From the kernel. See section midlevel codes

21.2 Status codes

The following status codes from the SCSI device (defined in `scsi/scsi.h`) are available.

Value	Symbol
0x00	GOOD
0x01	CHECK_CONDITION
0x02	CONDITION_GOOD
0x04	BUSY
0x08	INTERMEDIATE_GOOD
0x0a	INTERMEDIATE_C_GOOD

The Linux SCSI programming HOWTO

0x0c | RESERVATION_CONFLICT

Note that these symbol values have been **shifted right once**. When the status is CHECK_CONDITION, the sense data in the sense buffer is valid (check especially the additional sense code and additional sense code qualifier).

These values carry the meaning from the SCSI-2 specification:

Table 27: Status Byte Code

Bits of Status Byte								Status
7	6	5	4	3	2	1	0	
R	R	0	0	0	0	0	R	GOOD
R	R	0	0	0	0	1	R	CHECK CONDITION
R	R	0	0	0	1	0	R	CONDITION MET
R	R	0	0	1	0	0	R	BUSY
R	R	0	1	0	0	0	R	INTERMEDIATE
R	R	0	1	0	1	0	R	INTERMEDIATE-CONDITION MET
R	R	0	1	1	0	0	R	RESERVATION CONFLICT
R	R	1	0	0	0	1	R	COMMAND TERMINATED
R	R	1	0	1	0	0	R	QUEUE FULL
All Other Codes								Reserved
Key: R = Reserved bit								

A definition of the status byte codes is given below.

GOOD. This status indicates that the target has successfully completed the command.

CHECK CONDITION. This status indicates that a contingent allegiance condition has occurred (see 6.6).

CONDITION MET. This status or INTERMEDIATE-CONDITION MET is returned whenever the requested operation is satisfied (see the SEARCH DATA and PRE-FETCH commands).

BUSY. This status indicates that the target is busy. This status shall be returned whenever a target is unable to accept a command from an otherwise acceptable initiator (i.e., no reservation conflicts). The recommended initiator recovery action is to issue the command again at a later time.

INTERMEDIATE. This status or INTERMEDIATE-CONDITION MET shall be returned for every successfully completed command in a series of linked commands (except the last command), unless the command is terminated with CHECK CONDITION, RESERVATION CONFLICT, or COMMAND TERMINATED status. If INTERMEDIATE or INTERMEDIATE-CONDITION MET status is not returned, the series of linked commands is terminated and the I/O process is ended.

INTERMEDIATE-CONDITION MET. This status is the combination of the CONDITION MET and INTERMEDIATE statuses.

RESERVATION CONFLICT. This status shall be returned whenever an initiator

The Linux SCSI programming HOWTO

attempts to access a logical unit or an extent within a logical unit that is reserved with a conflicting reservation type for another SCSI device (see the RESERVE and RESERVE UNIT commands). The recommended initiator recovery action is to issue the command again at a later time.

COMMAND TERMINATED. This status shall be returned whenever the target terminates the current I/O process after receiving a TERMINATE I/O PROCESS message (see 5.6.22). This status also indicates that a contingent allegiance condition has occurred (see 6.6).

QUEUE FULL. This status shall be implemented if tagged queuing is implemented. This status is returned when a SIMPLE QUEUE TAG, ORDERED QUEUE TAG, or HEAD OF QUEUE TAG message is received and the command queue is full. The I/O process is not placed in the command queue.

21.3 SCSI Sense Keys

These kernel symbols (from `scsi/scsi.h`) are predefined:

Value	Symbol
0x00	NO_SENSE
0x01	RECOVERED_ERROR
0x02	NOT_READY
0x03	MEDIUM_ERROR
0x04	HARDWARE_ERROR
0x05	ILLEGAL_REQUEST
0x06	UNIT_ATTENTION
0x07	DATA_PROTECT
0x08	BLANK_CHECK
0x0a	COPY_ABORTED
0x0b	ABORTED_COMMAND
0x0d	VOLUME_OVERFLOW
0x0e	MISCOMPARE

A verbatim list from the SCSI-2 doc follows (from section 7.2.14.3):

Table 69: Sense Key (0h-7h) Descriptions

Sense Key	Description
0h	NO SENSE. Indicates that there is no specific sense key information to be reported for the designated logical unit. This would be the case for a successful command or a command that received CHECK CONDITION or COMMAND TERMINATED status because one of the filemark, EOM, or ILI bits is set to one.

The Linux SCSI programming HOWTO

1h	RECOVERED ERROR. Indicates that the last command completed successfully with some recovery action performed by the target. Details may be determinable by examining the additional sense bytes and the information field. When multiple recovered errors occur during one command, the choice of which error to report (first, last, most severe, etc.) is device specific.
2h	NOT READY. Indicates that the logical unit addressed cannot be accessed. Operator intervention may be required to correct this condition.
3h	MEDIUM ERROR. Indicates that the command terminated with a non-recovered error condition that was probably caused by a flaw in the medium or an error in the recorded data. This sense key may also be returned if the target is unable to distinguish between a flaw in the medium and a specific hardware failure (sense key 4h).
4h	HARDWARE ERROR. Indicates that the target detected a non-recoverable hardware failure (for example, controller failure, device failure, parity error, etc.) while performing the command or during a self test.
5h	ILLEGAL REQUEST. Indicates that there was an illegal parameter in the command descriptor block or in the additional parameters supplied as data for some commands (FORMAT UNIT, SEARCH DATA, etc.). If the target detects an invalid parameter in the command descriptor block, then it shall terminate the command without altering the medium. If the target detects an invalid parameter in the additional parameters supplied as data, then the target may have already altered the medium. This sense key may also indicate that an invalid IDENTIFY message was received (5.6.7).
6h	UNIT ATTENTION. Indicates that the removable medium may have been changed or the target has been reset. See 6.9 for more detailed information about the unit attention condition.
7h	DATA PROTECT. Indicates that a command that reads or writes the medium was attempted on a block that is protected from this operation. The read or write operation is not performed.

Table 70: Sense Key (8h-Fh) Descriptions

Sense Key	Description
8h	BLANK CHECK. Indicates that a write-once device or a sequential-access device encountered blank medium or format-defined end-of-data indication while reading or a write-once device encountered a non-blank medium while writing.
9h	Vendor Specific. This sense key is available for reporting vendor specific conditions.
Ah	COPY ABORTED. Indicates a COPY, COMPARE, or COPY AND VERIFY command was aborted due to an error condition on the source device, the destination device, or both. (See 7.2.3.2 for additional information about this sense key.)
Bh	ABORTED COMMAND. Indicates that the target aborted the command. The initiator may be able to recover by trying the command again.

The Linux SCSI programming HOWTO

Ch	EQUAL. Indicates a SEARCH DATA command has satisfied an equal comparison.
Dh	VOLUME OVERFLOW. Indicates that a buffered peripheral device has reached the end-of-partition and data may remain in the buffer that has not been written to the medium. A RECOVER BUFFERED DATA command(s) may be issued to read the unwritten data from the buffer.
Eh	MISCOMPARE. Indicates that the source data did not match the data read from the medium.
Fh	RESERVED.

21.4 Host codes

The following host codes are defined in `drivers/scsi/scsi.h`. They are set by the kernel driver.

Value	Symbol	Description
0x00	DID_OK	No error
0x01	DID_NO_CONNECT	Couldn't connect before timeout period
0x02	DID_BUS_BUSY	BUS stayed busy through time out period
0x03	DID_TIME_OUT	TIMED OUT for other reason
0x04	DID_BAD_TARGET	BAD target
0x05	DID_ABORT	Told to abort for some other reason
0x06	DID_PARITY	Parity error
0x07	DID_ERROR	internal error
0x08	DID_RESET	Reset by somebody
0x09	DID_BAD_INTR	Got an interrupt we weren't expecting

21.5 Driver codes

The midlevel driver categorizes the returned status from the lowlevel driver based on the sense key from the device. It suggests some actions to be taken such as retry, abort or remap. The routine `scsi_done` from `scsi.c` does a very differentiated handling based on `host_byte()`, `status_byte()`, `msg_byte()` and the suggestion. It then sets the driver byte to show what it has done. The driver byte is composed out of two nibbles: the driver status and the suggestion. Each half is composed from the below values being 'or'ed together (found in `scsi.h`).

Value	Symbol	Description of Driver status
0x00	DRIVER_OK	No error
0x01	DRIVER_BUSY	not used
0x02	DRIVER_SOFT	not used

The Linux SCSI programming HOWTO

0x03	DRIVER_MEDIA	not used
0x04	DRIVER_ERROR	internal driver error
0x05	DRIVER_INVALID	finished (DID_BAD_TARGET or DID_ABORT)
0x06	DRIVER_TIMEOUT	finished with timeout
0x07	DRIVER_HARD	finished with fatal error
0x08	DRIVER_SENSE	had sense information available

Value	Symbol	Description of suggestion
0x10	SUGGEST_RETRY	retry the SCSI request
0x20	SUGGEST_ABORT	abort the request
0x30	SUGGEST_REMAP	remap the block (not yet implemented)
0x40	SUGGEST_DIE	let the kernel panic
0x80	SUGGEST_SENSE	get sense information from the device
0xff	SUGGEST_IS_OK	nothing to be done

22. Additional sense codes and additional sense code qualifiers

When the status of the executed SCSI command is CHECK_CONDITION, sense data is available in the sense buffer. The additional sense code and additional sense code qualifier are contained in that buffer.

From the SCSI-2 specification I include two tables. The first is in lexical, the second in numerical order.

22.1 ASC and ASCQ in lexical order

The following table list gives a list of descriptions and device types they apply to.

```
+-----+
|          D - DIRECT ACCESS DEVICE
|          .T - SEQUENTIAL ACCESS DEVICE
|          . L - PRINTER DEVICE
|          . P - PROCESSOR DEVICE
|          . .W - WRITE ONCE READ MULTIPLE DEVICE
|          . . R - READ ONLY (CD-ROM) DEVICE
|          . . S - SCANNER DEVICE
|          . . .O - OPTICAL MEMORY DEVICE
|          . . . M - MEDIA CHANGER DEVICE
|          . . . C - COMMUNICATION DEVICE
|          . . . .
| ASC  ASCQ  DTLPWRSOMC  DESCRIPTION
|-----+-----+-----+-----+
| 13h  00h  D   W   O     ADDRESS MARK NOT FOUND FOR DATA FIELD
| 12h  00h  D   W   O     ADDRESS MARK NOT FOUND FOR ID FIELD
| 00h  11h           R     AUDIO PLAY OPERATION IN PROGRESS
+-----+-----+-----+-----+
```

The Linux SCSI programming HOWTO

00h	12h		R	AUDIO PLAY OPERATION PAUSED
00h	14h		R	AUDIO PLAY OPERATION STOPPED DUE TO ERROR
00h	13h		R	AUDIO PLAY OPERATION SUCCESSFULLY COMPLETED
00h	04h	T	S	BEGINNING-OF-PARTITION/MEDIUM DETECTED
14h	04h	T		BLOCK SEQUENCE ERROR
30h	02h	DT	WR O	CANNOT READ MEDIUM - INCOMPATIBLE FORMAT
30h	01h	DT	WR O	CANNOT READ MEDIUM - UNKNOWN FORMAT
52h	00h	T		CARTRIDGE FAULT
3Fh	02h	DTLPWRSOMC		CHANGED OPERATING DEFINITION
11h	06h		WR O	CIRC UNRECOVERED ERROR
30h	03h	DT		CLEANING CARTRIDGE INSTALLED
4Ah	00h	DTLPWRSOMC		COMMAND PHASE ERROR
2Ch	00h	DTLPWRSOMC		COMMAND SEQUENCE ERROR
2Fh	00h	DTLPWRSOMC		COMMANDS CLEARED BY ANOTHER INITIATOR
2Bh	00h	DTLPWRSO	C	COPY CANNOT EXECUTE SINCE HOST CANNOT DISCONNECT
41h	00h	D		DATA PATH FAILURE (SHOULD USE 40 NN)
4Bh	00h	DTLPWRSOMC		DATA PHASE ERROR
11h	07h		W O	DATA RESYNCHRONIZATION ERROR
16h	00h	D	W O	DATA SYNCHRONIZATION MARK ERROR
19h	00h	D	O	DEFECT LIST ERROR
19h	03h	D	O	DEFECT LIST ERROR IN GROWN LIST
19h	02h	D	O	DEFECT LIST ERROR IN PRIMARY LIST
19h	01h	D	O	DEFECT LIST NOT AVAILABLE
1Ch	00h	D	O	DEFECT LIST NOT FOUND
32h	01h	D	W O	DEFECT LIST UPDATE FAILURE
40h	NNh	DTLPWRSOMC		DIAGNOSTIC FAILURE ON COMPONENT NN (80H-FFH)
63h	00h		R	END OF USER AREA ENCOUNTERED ON THIS TRACK
00h	05h	T	S	END-OF-DATA DETECTED
14h	03h	T		END-OF-DATA NOT FOUND
00h	02h	T	S	END-OF-PARTITION/MEDIUM DETECTED
51h	00h	T	O	ERASE FAILURE
0Ah	00h	DTLPWRSOMC		ERROR LOG OVERFLOW
11h	02h	DT	W SO	ERROR TOO LONG TO CORRECT
03h	02h	T		EXCESSIVE WRITE ERRORS
3Bh	07h		L	FAILED TO SENSE BOTTOM-OF-FORM
3Bh	06h		L	FAILED TO SENSE TOP-OF-FORM
00h	01h	T		FILEMARK DETECTED
14h	02h	T		FILEMARK OR SETMARK NOT FOUND
09h	02h		WR O	FOCUS SERVO FAILURE
31h	01h	D L	O	FORMAT COMMAND FAILED
58h	00h		O	GENERATION DOES NOT EXIST

Table 71: (continued)

ASC	ASCQ	DTLPWRSOMC		DESCRIPTION
1Ch	02h	D	O	GROWN DEFECT LIST NOT FOUND
00h	06h	DTLPWRSOMC		I/O PROCESS TERMINATED
10h	00h	D	W O	ID CRC OR ECC ERROR
22h	00h	D		ILLEGAL FUNCTION (SHOULD USE 20 00, 24 00, OR 26 00)
64h	00h		R	ILLEGAL MODE FOR THIS TRACK
28h	01h		M	IMPORT OR EXPORT ELEMENT ACCESSED
30h	00h	DT	WR OM	INCOMPATIBLE MEDIUM INSTALLED
11h	08h	T		INCOMPLETE BLOCK READ
48h	00h	DTLPWRSOMC		INITIATOR DETECTED ERROR MESSAGE RECEIVED
3Fh	03h	DTLPWRSOMC		INQUIRY DATA HAS CHANGED
44h	00h	DTLPWRSOMC		INTERNAL TARGET FAILURE

The Linux SCSI programming HOWTO

3Dh	00h	DTLPWRSOMC	INVALID BITS IN IDENTIFY MESSAGE
2Ch	02h	S	INVALID COMBINATION OF WINDOWS SPECIFIED
20h	00h	DTLPWRSOMC	INVALID COMMAND OPERATION CODE
21h	01h	M	INVALID ELEMENT ADDRESS
24h	00h	DTLPWRSOMC	INVALID FIELD IN CDB
26h	00h	DTLPWRSOMC	INVALID FIELD IN PARAMETER LIST
49h	00h	DTLPWRSOMC	INVALID MESSAGE ERROR
11h	05h	WR O	L-EC UNCORRECTABLE ERROR
60h	00h	S	LAMP FAILURE
5Bh	02h	DTLPWRSOM	LOG COUNTER AT MAXIMUM
5Bh	00h	DTLPWRSOM	LOG EXCEPTION
5Bh	03h	DTLPWRSOM	LOG LIST CODES EXHAUSTED
2Ah	02h	DTL WRSOMC	LOG PARAMETERS CHANGED
21h	00h	DT WR OM	LOGICAL BLOCK ADDRESS OUT OF RANGE
08h	00h	DTL WRSOMC	LOGICAL UNIT COMMUNICATION FAILURE
08h	02h	DTL WRSOMC	LOGICAL UNIT COMMUNICATION PARITY ERROR
08h	01h	DTL WRSOMC	LOGICAL UNIT COMMUNICATION TIME-OUT
4Ch	00h	DTLPWRSOMC	LOGICAL UNIT FAILED SELF-CONFIGURATION
3Eh	00h	DTLPWRSOMC	LOGICAL UNIT HAS NOT SELF-CONFIGURED YET
04h	01h	DTLPWRSOMC	LOGICAL UNIT IS IN PROCESS OF BECOMING READY
04h	00h	DTLPWRSOMC	LOGICAL UNIT NOT READY, CAUSE NOT REPORTABLE
04h	04h	DTL O	LOGICAL UNIT NOT READY, FORMAT IN PROGRESS
04h	02h	DTLPWRSOMC	LOGICAL UNIT NOT READY, INITIALIZING COMMAND REQUIRED
04h	03h	DTLPWRSOMC	LOGICAL UNIT NOT READY, MANUAL INTERVENTION REQUIRED
25h	00h	DTLPWRSOMC	LOGICAL UNIT NOT SUPPORTED
15h	01h	DTL WRSOM	MECHANICAL POSITIONING ERROR
53h	00h	DTL WRSOM	MEDIA LOAD OR EJECT FAILED
3Bh	0Dh	M	MEDIUM DESTINATION ELEMENT FULL
31h	00h	DT W O	MEDIUM FORMAT CORRUPTED
3Ah	00h	DTL WRSOM	MEDIUM NOT PRESENT
53h	02h	DT WR OM	MEDIUM REMOVAL PREVENTED
3Bh	0Eh	M	MEDIUM SOURCE ELEMENT EMPTY
43h	00h	DTLPWRSOMC	MESSAGE ERROR
3Fh	01h	DTLPWRSOMC	MICROCODE HAS BEEN CHANGED
1Dh	00h	D W O	MISCOMPARE DURING VERIFY OPERATION
11h	0Ah	DT O	MISCORRECTED ERROR
2Ah	01h	DTL WRSOMC	MODE PARAMETERS CHANGED
07h	00h	DTL WRSOM	MULTIPLE PERIPHERAL DEVICES SELECTED
11h	03h	DT W SO	MULTIPLE READ ERRORS
00h	00h	DTLPWRSOMC	NO ADDITIONAL SENSE INFORMATION
00h	15h	R	NO CURRENT AUDIO STATUS TO RETURN
32h	00h	D W O	NO DEFECT SPARE LOCATION AVAILABLE
11h	09h	T	NO GAP FOUND
01h	00h	D W O	NO INDEX/SECTOR SIGNAL
06h	00h	D WR OM	NO REFERENCE POSITION FOUND

Table 71: (continued)

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
02h	00h	D WR OM	NO SEEK COMPLETE
03h	01h	T	NO WRITE CURRENT
28h	00h	DTLPWRSOMC	NOT READY TO READY TRANSITION, MEDIUM MAY HAVE CHANGED
5Ah	01h	DT WR OM	OPERATOR MEDIUM REMOVAL REQUEST
5Ah	00h	DTLPWRSOM	OPERATOR REQUEST OR STATE CHANGE INPUT (UNSPECIFIED)
5Ah	03h	DT W O	OPERATOR SELECTED WRITE PERMIT
5Ah	02h	DT W O	OPERATOR SELECTED WRITE PROTECT

The Linux SCSI programming HOWTO

61h	02h	S	OUT OF FOCUS
4Eh	00h	DTLPWRSOMC	OVERLAPPED COMMANDS ATTEMPTED
2Dh	00h	T	OVERWRITE ERROR ON UPDATE IN PLACE
3Bh	05h	L	PAPER JAM
1Ah	00h	DTLPWRSOMC	PARAMETER LIST LENGTH ERROR
26h	01h	DTLPWRSOMC	PARAMETER NOT SUPPORTED
26h	02h	DTLPWRSOMC	PARAMETER VALUE INVALID
2Ah	00h	DTL WRSOMC	PARAMETERS CHANGED
03h	00h	DTL W SO	PERIPHERAL DEVICE WRITE FAULT
50h	02h	T	POSITION ERROR RELATED TO TIMING
3Bh	0Ch	S	POSITION PAST BEGINNING OF MEDIUM
3Bh	0Bh	S	POSITION PAST END OF MEDIUM
15h	02h	DT WR O	POSITIONING ERROR DETECTED BY READ OF MEDIUM
29h	00h	DTLPWRSOMC	POWER ON, RESET, OR BUS DEVICE RESET OCCURRED
42h	00h	D	POWER-ON OR SELF-TEST FAILURE (SHOULD USE 40 NN)
1Ch	01h	D O	PRIMARY DEFECT LIST NOT FOUND
40h	00h	D	RAM FAILURE (SHOULD USE 40 NN)
15h	00h	DTL WRSOM	RANDOM POSITIONING ERROR
3Bh	0Ah	S	READ PAST BEGINNING OF MEDIUM
3Bh	09h	S	READ PAST END OF MEDIUM
11h	01h	DT W SO	READ RETRIES EXHAUSTED
14h	01h	DT WR O	RECORD NOT FOUND
14h	00h	DTL WRSO	RECORDED ENTITY NOT FOUND
18h	02h	D WR O	RECOVERED DATA - DATA AUTO-REALLOCATED
18h	05h	D WR O	RECOVERED DATA - RECOMMEND REASSIGNMENT
18h	06h	D WR O	RECOVERED DATA - RECOMMEND REWRITE
17h	05h	D WR O	RECOVERED DATA USING PREVIOUS SECTOR ID
18h	03h	R	RECOVERED DATA WITH CIRC
18h	01h	D WR O	RECOVERED DATA WITH ERROR CORRECTION & RETRIES APPLIED
18h	00h	DT WR O	RECOVERED DATA WITH ERROR CORRECTION APPLIED
18h	04h	R	RECOVERED DATA WITH L-EC
17h	03h	DT WR O	RECOVERED DATA WITH NEGATIVE HEAD OFFSET
17h	00h	DT WRSO	RECOVERED DATA WITH NO ERROR CORRECTION APPLIED
17h	02h	DT WR O	RECOVERED DATA WITH POSITIVE HEAD OFFSET
17h	01h	DT WRSO	RECOVERED DATA WITH RETRIES
17h	04h	WR O	RECOVERED DATA WITH RETRIES AND/OR CIRC APPLIED
17h	06h	D W O	RECOVERED DATA WITHOUT ECC - DATA AUTO-REALLOCATED
17h	07h	D W O	RECOVERED DATA WITHOUT ECC - RECOMMEND REASSIGNMENT
17h	08h	D W O	RECOVERED DATA WITHOUT ECC - RECOMMEND REWRITE
1Eh	00h	D W O	RECOVERED ID WITH ECC CORRECTION
3Bh	08h	T	REPOSITION ERROR
36h	00h	L	RIBBON, INK, OR TONER FAILURE
37h	00h	DTL WRSOMC	ROUNDED PARAMETER
5Ch	00h	D O	RPL STATUS CHANGE
39h	00h	DTL WRSOMC	SAVING PARAMETERS NOT SUPPORTED
62h	00h	S	SCAN HEAD POSITIONING ERROR
47h	00h	DTLPWRSOMC	SCSI PARITY ERROR
54h	00h	P	SCSI TO HOST SYSTEM INTERFACE FAILURE
45h	00h	DTLPWRSOMC	SELECT OR RESELECT FAILURE

Table 71: (concluded)

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
3Bh	00h	TL	SEQUENTIAL POSITIONING ERROR
00h	03h	T	SETMARK DETECTED
3Bh	04h	L	SLEW FAILURE

The Linux SCSI programming HOWTO

09h	03h	WR	O	SPINDLE SERVO FAILURE
5Ch	02h	D	O	SPINDLES NOT SYNCHRONIZED
5Ch	01h	D	O	SPINDLES SYNCHRONIZED
1Bh	00h	DTLPWRSOMC		SYNCHRONOUS DATA TRANSFER ERROR
55h	00h	P		SYSTEM RESOURCE FAILURE
33h	00h	T		TAPE LENGTH ERROR
3Bh	03h	L		TAPE OR ELECTRONIC VERTICAL FORMS UNIT NOT READY
3Bh	01h	T		TAPE POSITION ERROR AT BEGINNING-OF-MEDIUM
3Bh	02h	T		TAPE POSITION ERROR AT END-OF-MEDIUM
3Fh	00h	DTLPWRSOMC		TARGET OPERATING CONDITIONS HAVE CHANGED
5Bh	01h	DTLPWRSOM		THRESHOLD CONDITION MET
26h	03h	DTLPWRSOMC		THRESHOLD PARAMETERS NOT SUPPORTED
2Ch	01h	S		TOO MANY WINDOWS SPECIFIED
09h	00h	DT	WR O	TRACK FOLLOWING ERROR
09h	01h		WR O	TRACKING SERVO FAILURE
61h	01h		S	UNABLE TO ACQUIRE VIDEO
57h	00h		R	UNABLE TO RECOVER TABLE-OF-CONTENTS
53h	01h	T		UNLOAD TAPE FAILURE
11h	00h	DT	WRSO	UNRECOVERED READ ERROR
11h	04h	D	W O	UNRECOVERED READ ERROR - AUTO REALLOCATE FAILED
11h	0Bh	D	W O	UNRECOVERED READ ERROR - RECOMMEND REASSIGNMENT
11h	0Ch	D	W O	UNRECOVERED READ ERROR - RECOMMEND REWRITE THE DATA
46h	00h	DTLPWRSOMC		UNSUCCESSFUL SOFT RESET
59h	00h		O	UPDATED BLOCK READ
61h	00h		S	VIDEO ACQUISITION ERROR
50h	00h	T		WRITE APPEND ERROR
50h	01h	T		WRITE APPEND POSITION ERROR
0Ch	00h	T	S	WRITE ERROR
0Ch	02h	D	W O	WRITE ERROR - AUTO REALLOCATION FAILED
0Ch	01h	D	W O	WRITE ERROR RECOVERED WITH AUTO REALLOCATION
27h	00h	DT	W O	WRITE PROTECTED
80h	XXh	\		
THROUGH		>		VENDOR SPECIFIC.
FFh	XX	/		
XXh	80h	\		
THROUGH		>		VENDOR SPECIFIC QUALIFICATION OF STANDARD ASC.
XXh	FFh	/		
				ALL CODES NOT SHOWN ARE RESERVED.

22.2 ASC and ASCQ in numerical order

Table 364: ASC and ASCQ Assignments

D	-	DIRECT ACCESS DEVICE
.T	-	SEQUENTIAL ACCESS DEVICE
.L	-	PRINTER DEVICE
.P	-	PROCESSOR DEVICE
.W	-	WRITE ONCE READ MULTIPLE DEVICE
.R	-	READ ONLY (CD-ROM) DEVICE
.S	-	SCANNER DEVICE

The Linux SCSI programming HOWTO

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
			. . . O - OPTICAL MEMORY DEVICE
			. . . M - MEDIA CHANGER DEVICE
			. . . C - COMMUNICATION DEVICE
		
00	00	DTLPWRSOMC	NO ADDITIONAL SENSE INFORMATION
00	01	T	FILEMARK DETECTED
00	02	T S	END-OF-PARTITION/MEDIUM DETECTED
00	03	T	SETMARK DETECTED
00	04	T S	BEGINNING-OF-PARTITION/MEDIUM DETECTED
00	05	T S	END-OF-DATA DETECTED
00	06	DTLPWRSOMC	I/O PROCESS TERMINATED
00	11	R	AUDIO PLAY OPERATION IN PROGRESS
00	12	R	AUDIO PLAY OPERATION PAUSED
00	13	R	AUDIO PLAY OPERATION SUCCESSFULLY COMPLETED
00	14	R	AUDIO PLAY OPERATION STOPPED DUE TO ERROR
00	15	R	NO CURRENT AUDIO STATUS TO RETURN
01	00	DW O	NO INDEX/SECTOR SIGNAL
02	00	DWR OM	NO SEEK COMPLETE
03	00	DTL W SO	PERIPHERAL DEVICE WRITE FAULT
03	01	T	NO WRITE CURRENT
03	02	T	EXCESSIVE WRITE ERRORS
04	00	DTLPWRSOMC	LOGICAL UNIT NOT READY, CAUSE NOT REPORTABLE
04	01	DTLPWRSOMC	LOGICAL UNIT IS IN PROCESS OF BECOMING READY
04	02	DTLPWRSOMC	LOGICAL UNIT NOT READY, INITIALIZING COMMAND REQUIRED
04	03	DTLPWRSOMC	LOGICAL UNIT NOT READY, MANUAL INTERVENTION REQUIRED
04	04	DTL O	LOGICAL UNIT NOT READY, FORMAT IN PROGRESS
05	00	DTL WRSOMC	LOGICAL UNIT DOES NOT RESPOND TO SELECTION
06	00	DWR OM NO	REFERENCE POSITION FOUND
07	00	DTL WRSOM	MULTIPLE PERIPHERAL DEVICES SELECTED
08	00	DTL WRSOMC	LOGICAL UNIT COMMUNICATION FAILURE
08	01	DTL WRSOMC	LOGICAL UNIT COMMUNICATION TIME-OUT
08	02	DTL WRSOMC	LOGICAL UNIT COMMUNICATION PARITY ERROR
09	00	DT WR O	TRACK FOLLOWING ERROR
09	01	WR O	TRACKING SERVO FAILURE
09	02	WR O	FOCUS SERVO FAILURE
09	03	WR O	SPI NDLE SERVO FAILURE

Table 364: (continued)

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
			D - DIRECT ACCESS DEVICE
			.T - SEQUENTIAL ACCESS DEVICE
			. L - PRINTER DEVICE
			. P - PROCESSOR DEVICE
			. .W - WRITE ONCE READ MULTIPLE DEVICE
			. . R - READ ONLY (CD-ROM) DEVICE
			. . S - SCANNER DEVICE
			. . . O - OPTICAL MEMORY DEVICE
			. . . M - MEDIA CHANGER DEVICE
			. . . C - COMMUNICATION DEVICE
		
0A	00	DTLPWRSOMC	ERROR LOG OVERFLOW
0B	00		
0C	00	T S	WRITE ERROR

The Linux SCSI programming HOWTO

0C 01	D	W	O	WRITE ERROR RECOVERED WITH AUTO REALLOCATION
0C 02	D	W	O	WRITE ERROR - AUTO REALLOCATION FAILED
0D 00				
0E 00				
0F 00				
10 00	D	W	O	ID CRC OR ECC ERROR
11 00	DT	W	SO	UNRECOVERED READ ERROR
11 01	DT	W	SO	READ RETRIES EXHAUSTED
11 02	DT	W	SO	ERROR TOO LONG TO CORRECT
11 03	DT	W	SO	MULTIPLE READ ERRORS
11 04	D	W	O	UNRECOVERED READ ERROR - AUTO REALLOCATE FAILED
11 05		WR	O	L-EC UNCORRECTABLE ERROR
11 06		WR	O	CIRC UNRECOVERED ERROR
11 07		W	O	DATA RESYNCHRONIZATION ERROR
11 08		T		INCOMPLETE BLOCK READ
11 09		T		NO GAP FOUND
11 0A	DT		O	MISCORRECTED ERROR
11 0B	D	W	O	UNRECOVERED READ ERROR - RECOMMEND REASSIGNMENT
11 0C	D	W	O	UNRECOVERED READ ERROR - RECOMMEND REWRITE THE DATA
12 00	D	W	O	ADDRESS MARK NOT FOUND FOR ID FIELD
13 00	D	W	O	ADDRESS MARK NOT FOUND FOR DATA FIELD
14 00	DTL	W	SO	RECORDED ENTITY NOT FOUND
14 01	DT	WR	O	RECORD NOT FOUND
14 02		T		FILEMARK OR SETMARK NOT FOUND
14 03		T		END-OF-DATA NOT FOUND
14 04		T		BLOCK SEQUENCE ERROR
15 00	DTL	W	SOM	RANDOM POSITIONING ERROR
15 01	DTL	W	SOM	MECHANICAL POSITIONING ERROR
15 02	DT	WR	O	POSITIONING ERROR DETECTED BY READ OF MEDIUM
16 00	DW		O	DATA SYNCHRONIZATION MARK ERROR
17 00	DT	W	SO	RECOVERED DATA WITH NO ERROR CORRECTION APPLIED
17 01	DT	W	SO	RECOVERED DATA WITH RETRIES
17 02	DT	WR	O	RECOVERED DATA WITH POSITIVE HEAD OFFSET
17 03	DT	WR	O	RECOVERED DATA WITH NEGATIVE HEAD OFFSET
17 04		WR	O	RECOVERED DATA WITH RETRIES AND/OR CIRC APPLIED
17 05	D	WR	O	RECOVERED DATA USING PREVIOUS SECTOR ID
17 06	D	W	O	RECOVERED DATA WITHOUT ECC - DATA AUTO-REALLOCATED
17 07	D	W	O	RECOVERED DATA WITHOUT ECC - RECOMMEND REASSIGNMENT
17 08	D	W	O	RECOVERED DATA WITHOUT ECC - RECOMMEND REWRITE
18 00	DT	WR	O	RECOVERED DATA WITH ERROR CORRECTION APPLIED
18 01	D	WR	O	RECOVERED DATA WITH ERROR CORRECTION & RETRIES APPLIED
18 02	D	WR	O	RECOVERED DATA - DATA AUTO-REALLOCATED
18 03		R		RECOVERED DATA WITH CIRC
18 04		R		RECOVERED DATA WITH LEC
18 05	D	WR	O	RECOVERED DATA - RECOMMEND REASSIGNMENT
18 06	D	WR	O	RECOVERED DATA - RECOMMEND REWRITE

Table 364: (continued)

D	-	DIRECT ACCESS DEVICE
.T	-	SEQUENTIAL ACCESS DEVICE
.L	-	PRINTER DEVICE
.P	-	PROCESSOR DEVICE
.W	-	WRITE ONCE READ MULTIPLE DEVICE
.R	-	READ ONLY (CD-ROM) DEVICE
.S	-	SCANNER DEVICE
.O	-	OPTICAL MEMORY DEVICE

The Linux SCSI programming HOWTO

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
			. . . M - MEDIA CHANGER DEVICE
			. . . C - COMMUNICATION DEVICE
		
19	00	D O	DEFECT LIST ERROR
19	01	D O	DEFECT LIST NOT AVAILABLE
19	02	D O	DEFECT LIST ERROR IN PRIMARY LIST
19	03	D O	DEFECT LIST ERROR IN GROWN LIST
1A	00	DTLPWRSOMC	PARAMETER LIST LENGTH ERROR
1B	00	DTLPWRSOMC	SYNCHRONOUS DATA TRANSFER ERROR
1C	00	D O	DEFECT LIST NOT FOUND
1C	01	D O	PRIMARY DEFECT LIST NOT FOUND
1C	02	D O	GROWN DEFECT LIST NOT FOUND
1D	00	D W O	MISCOMPARE DURING VERIFY OPERATION
1E	00	D W O	RECOVERED ID WITH ECC
1F	00		
20	00	DTLPWRSOMC	INVALID COMMAND OPERATION CODE
21	00	DT WR OM	LOGICAL BLOCK ADDRESS OUT OF RANGE
21	01	M	INVALID ELEMENT ADDRESS
22	00	D	ILLEGAL FUNCTION (SHOULD USE 20 00, 24 00, OR 26 00)
23	00		
24	00	DTLPWRSOMC	INVALID FIELD IN CDB
25	00	DTLPWRSOMC	LOGICAL UNIT NOT SUPPORTED
26	00	DTLPWRSOMC	INVALID FIELD IN PARAMETER LIST
26	01	DTLPWRSOMC	PARAMETER NOT SUPPORTED
26	02	DTLPWRSOMC	PARAMETER VALUE INVALID
26	03	DTLPWRSOMC	THRESHOLD PARAMETERS NOT SUPPORTED
27	00	DT W O	WRITE PROTECTED
28	00	DTLPWRSOMC	NOT READY TO READY TRANSITION(MEDIUM MAY HAVE CHANGED)
28	01	M	IMPORT OR EXPORT ELEMENT ACCESSED
29	00	DTLPWRSOMC	POWER ON, RESET, OR BUS DEVICE RESET OCCURRED
2A	00	DTL WRSOMC	PARAMETERS CHANGED
2A	01	DTL WRSOMC	MODE PARAMETERS CHANGED
2A	02	DTL WRSOMC	LOG PARAMETERS CHANGED
2B	00	DTLPWRSO C	COPY CANNOT EXECUTE SINCE HOST CANNOT DISCONNECT
2C	00	DTLPWRSOMC	COMMAND SEQUENCE ERROR
2C	01	S	TOO MANY WINDOWS SPECIFIED
2C	02	S	INVALID COMBINATION OF WINDOWS SPECIFIED
2D	00	T	OVERWRITE ERROR ON UPDATE IN PLACE
2E	00		
2F	00	DTLPWRSOMC	COMMANDS CLEARED BY ANOTHER INITIATOR
30	00	DT WR OM	INCOMPATIBLE MEDIUM INSTALLED
30	01	DT WR O	CANNOT READ MEDIUM - UNKNOWN FORMAT
30	02	DT WR O	CANNOT READ MEDIUM - INCOMPATIBLE FORMAT
30	03	DT	CLEANING CARTRIDGE INSTALLED
31	00	DT W O	MEDIUM FORMAT CORRUPTED
31	01	D L O	FORMAT COMMAND FAILED
32	00	D W O	NO DEFECT SPARE LOCATION AVAILABLE
32	01	D W O	DEFECT LIST UPDATE FAILURE
33	00	T	TAPE LENGTH ERROR
34	00		
35	00		
36	00	L	RIBBON, INK, OR TONER FAILURE

Table 364: (continued)

The Linux SCSI programming HOWTO

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
			D - DIRECT ACCESS DEVICE
			.T - SEQUENTIAL ACCESS DEVICE
			. L - PRINTER DEVICE
			. P - PROCESSOR DEVICE
			. .W - WRITE ONCE READ MULTIPLE DEVICE
			. . R - READ ONLY (CD-ROM) DEVICE
			. . S - SCANNER DEVICE
			. . .O - OPTICAL MEMORY DEVICE
			. . . M - MEDIA CHANGER DEVICE
			. . . C - COMMUNICATION DEVICE
		
37	00	DTL WRSOMC	ROUNDED PARAMETER
38	00		
39	00	DTL WRSOMC	SAVING PARAMETERS NOT SUPPORTED
3A	00	DTL WRSOMC	MEDIUM NOT PRESENT
3B	00	TL	SEQUENTIAL POSITIONING ERROR
3B	01	T	TAPE POSITION ERROR AT BEGINNING-OF-MEDIUM
3B	02	T	TAPE POSITION ERROR AT END-OF-MEDIUM
3B	03	L	TAPE OR ELECTRONIC VERTICAL FORMS UNIT NOT READY
3B	04	L	SLEW FAILURE
3B	05	L	PAPER JAM
3B	06	L	FAILED TO SENSE TOP-OF-FORM
3B	07	L	FAILED TO SENSE BOTTOM-OF-FORM
3B	08	T	REPOSITION ERROR
3B	09	S	READ PAST END OF MEDIUM
3B	0A	S	READ PAST BEGINNING OF MEDIUM
3B	0B	S	POSITION PAST END OF MEDIUM
3B	0C	S	POSITION PAST BEGINNING OF MEDIUM
3B	0D	M	MEDIUM DESTINATION ELEMENT FULL
3B	0E	M	MEDIUM SOURCE ELEMENT EMPTY
3C	00		
3D	00	DTLPWRSOMC	INVALID BITS IN IDENTIFY MESSAGE
3E	00	DTLPWRSOMC	LOGICAL UNIT HAS NOT SELF-CONFIGURED YET
3F	00	DTLPWRSOMC	TARGET OPERATING CONDITIONS HAVE CHANGED
3F	01	DTLPWRSOMC	MICROCODE HAS BEEN CHANGED
3F	02	DTLPWRSOMC	CHANGED OPERATING DEFINITION
3F	03	DTLPWRSOMC	INQUIRY DATA HAS CHANGED
40	00	D	RAM FAILURE (SHOULD USE 40 NN)
40	NN	DTLPWRSOMC	DIAGNOSTIC FAILURE ON COMPONENT NN (80H-FFH)
41	00	D	DATA PATH FAILURE (SHOULD USE 40 NN)
42	00	D	POWER-ON OR SELF-TEST FAILURE (SHOULD USE 40 NN)
43	00	DTLPWRSOMC	MESSAGE ERROR
44	00	DTLPWRSOMC	INTERNAL TARGET FAILURE
45	00	DTLPWRSOMC	SELECT OR RESELECT FAILURE
46	00	DTLPWRSOMC	UNSUCCESSFUL SOFT RESET
47	00	DTLPWRSOMC	SCSI PARITY ERROR
48	00	DTLPWRSOMC	INITIATOR DETECTED ERROR MESSAGE RECEIVED
49	00	DTLPWRSOMC	INVALID MESSAGE ERROR
4A	00	DTLPWRSOMC	COMMAND PHASE ERROR
4B	00	DTLPWRSOMC	DATA PHASE ERROR
4C	00	DTLPWRSOMC	LOGICAL UNIT FAILED SELF-CONFIGURATION
4D	00		
4E	00	DTLPWRSOMC	OVERLAPPED COMMANDS ATTEMPTED
4F	00		
50	00	T	WRITE APPEND ERROR
50	01	T	WRITE APPEND POSITION ERROR
50	02	T	POSITION ERROR RELATED TO TIMING
51	00	T O	ERASE FAILURE
52	00	T	CARTRIDGE FAULT

The Linux SCSI programming HOWTO

Table 364: (continued)

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
		D	DIRECT ACCESS DEVICE
		.T	SEQUENTIAL ACCESS DEVICE
		.L	PRINTER DEVICE
		.P	PROCESSOR DEVICE
		.W	WRITE ONCE READ MULTIPLE DEVICE
		.R	READ ONLY (CD-ROM) DEVICE
		.S	SCANNER DEVICE
		.O	OPTICAL MEMORY DEVICE
		.M	MEDIA CHANGER DEVICE
		.C	COMMUNICATION DEVICE
		.	.
		.	.
ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
53	00	DTL WRSOM	MEDIA LOAD OR EJECT FAILED
53	01	T	UNLOAD TAPE FAILURE
53	02	DT WR OM	MEDIUM REMOVAL PREVENTED
54	00	P	SCSI TO HOST SYSTEM INTERFACE FAILURE
55	00	P	SYSTEM RESOURCE FAILURE
56	00		
57	00	R	UNABLE TO RECOVER TABLE-OF-CONTENTS
58	00	O	GENERATION DOES NOT EXIST
59	00	O	UPDATED BLOCK READ
5A	00	DTLPWRSOM	OPERATOR REQUEST OR STATE CHANGE INPUT (UNSPECIFIED)
5A	01	DT WR OM	OPERATOR MEDIUM REMOVAL REQUEST
5A	02	DT W O	OPERATOR SELECTED WRITE PROTECT
5A	03	DT W O	OPERATOR SELECTED WRITE PERMIT
5B	00	DTLPWRSOM	LOG EXCEPTION
5B	01	DTLPWRSOM	THRESHOLD CONDITION MET
5B	02	DTLPWRSOM	LOG COUNTER AT MAXIMUM
5B	03	DTLPWRSOM	LOG LIST CODES EXHAUSTED
5C	00	D O	RPL STATUS CHANGE
5C	01	D O	SPINDLES SYNCHRONIZED
5C	02	D O	SPINDLES NOT SYNCHRONIZED
5D	00		
5E	00		
5F	00		
60	00	S	LAMP FAILURE
61	00	S	VIDEO ACQUISITION ERROR
61	01	S	UNABLE TO ACQUIRE VIDEO
61	02	S	OUT OF FOCUS
62	00	S	SCAN HEAD POSITIONING ERROR
63	00	R	END OF USER AREA ENCOUNTERED ON THIS TRACK
64	00	R	ILLEGAL MODE FOR THIS TRACK
65	00		
66	00		
67	00		
68	00		
69	00		
6A	00		
6B	00		
6C	00		
6D	00		
6E	00		
6F	00		

The Linux SCSI programming HOWTO

Table 364: (concluded)

ASC	ASCQ	DTLPWRSOMC	DESCRIPTION
			D - DIRECT ACCESS DEVICE
			.T - SEQUENTIAL ACCESS DEVICE
			. L - PRINTER DEVICE
			. P - PROCESSOR DEVICE
			. .W - WRITE ONCE READ MULTIPLE DEVICE
			. . R - READ ONLY (CD-ROM) DEVICE
			. . S - SCANNER DEVICE
			. . .O - OPTICAL MEMORY DEVICE
			. . . M - MEDIA CHANGER DEVICE
			. . . C - COMMUNICATION DEVICE
		
70	00		
71	00		
72	00		
73	00		
74	00		
75	00		
76	00		
77	00		
78	00		
79	00		
7A	00		
7B	00		
7C	00		
7D	00		
7E	00		
7F	00		
80	xxh \		THROUGH > VENDOR SPECIFIC.
FF	xxh /		
xxh	80 \		THROUGH > VENDOR SPECIFIC QUALIFICATION OF STANDARD ASC.
xxh	FF /		
ALL CODES NOT SHOWN OR BLANK ARE RESERVED.			

23.A SCSI command code quick reference

Table 365 is a numerical order listing of the command operation codes.

Table 365: SCSI-2 Operation Codes

D - DIRECT ACCESS DEVICE	Device Column Key
.T - SEQUENTIAL ACCESS DEVICE	M = Mandatory
. L - PRINTER DEVICE	O = Optional
. P - PROCESSOR DEVICE	V = Vendor Specific
. .W - WRITE ONCE READ MULTIPLE DEVICE	R = Reserved

The Linux SCSI programming HOWTO

	. . R	- READ ONLY (CD-ROM) DEVICE		
	. . S	- SCANNER DEVICE		
	. . .O	- OPTICAL MEMORY DEVICE		
	. . . M	- MEDIA CHANGER DEVICE		
	. . . C	- COMMUNICATION DEVICE		
			
OP DTLPWR SOMC Description				
00	MMMMMMMM	TEST UNIT READY		
01	M	REWIND		
01	O V OO OO	REZERO UNIT		
02	VVVVVV	V		
03	MMMMMMMM	REQUEST SENSE		
04	O	FORMAT		
04	M O	FORMAT UNIT		
05	VMVVVV	V READ BLOCK LIMITS		
06	VVVVVV	V		
07		O INITIALIZE ELEMENT STATUS		
07	OVV O OV	REASSIGN BLOCKS		
08		M GET MESSAGE(06)		
08	OMV OO OV	READ(06)		
08	O	RECEIVE		
09	VVVVVV	V		
0A	M	PRINT		
0A		M SEND MESSAGE(06)		
0A	M	SEND(06)		
0A	OM O OV	WRITE(06)		
0B	O OO OV	SEEK(06)		
0B	O	SLEW AND PRINT		
0C	VVVVVV	V		
0D	VVVVVV	V		
0E	VVVVVV	V		
0F	VOVVVV	V READ REVERSE		
10	O O	SYNCHRONIZE BUFFER		
10	VM VVV	WRITE FILEMARKS		
11	VMVVVV	SPACE		
12	MMMMMMMM	INQUIRY		
13	VOVVVV	VERIFY(06)		
14	VOVVVV	RECOVER BUFFERED DATA		
15	OMO OOOOOO	MODE SELECT(06)		
16	M MM MO	RESERVE		
16	MM M	RESERVE UNIT		
17	M MM MO	RELEASE		
17	MM M	RELEASE UNIT		
18	OOOOOOO	COPY		
19	VMVVVV	ERASE		
1A	OMO OOOOOO	MODE SENSE(06)		
1B	O	LOAD UNLOAD		
1B		O SCAN		
1B	O	STOP PRINT		
1B	O OO O	STOP START UNIT		

Table 365: (continued)

	D - DIRECT ACCESS DEVICE	Device Column Key
	.T - SEQUENTIAL ACCESS DEVICE	M = Mandatory
	. L - PRINTER DEVICE	O = Optional

The Linux SCSI programming HOWTO

Table 365: (continued)

		Device Column Key
D	- DIRECT ACCESS DEVICE	M = Mandatory
.T	- SEQUENTIAL ACCESS DEVICE	O = Optional
.L	- PRINTER DEVICE	V = Vendor Specific
.P	- PROCESSOR DEVICE	R = Reserved
.W	- WRITE ONCE READ MULTIPLE DEVICE	
.R	- READ ONLY (CD-ROM) DEVICE	
.S	- SCANNER DEVICE	
.O	- OPTICAL MEMORY DEVICE	
.M	- MEDIA CHANGER DEVICE	
.C	- COMMUNICATION DEVICE	
. . .		
OP	DTLPWRSOMC	Description
40	000000000	CHANGE DEFINITION
41	O	WRITE SAME
42	O	READ SUB-CHANNEL
43	O	READ TOC
44	O	READ HEADER
45	O	PLAY AUDIO(10)
46		
47	O	PLAY AUDIO MSF
48	O	PLAY AUDIO TRACK INDEX
49	O	PLAY TRACK RELATIVE(10)
4A		
4B	O	PAUSE RESUME
4C	000000000	LOG SELECT
4D	000000000	LOG SENSE
4E		
4F		
50		
51		
52		
53		
54		
55	000 000000	MODE SELECT(10)
56		
57		
58		
59		
5A	000 000000	MODE SENSE(10)
5B		
5C		
5D		
5E		
5F		

Table 365: (concluded)

D	- DIRECT ACCESS DEVICE	Device Column Key
.T	- SEQUENTIAL ACCESS DEVICE	M = Mandatory
.L	- PRINTER DEVICE	O = Optional
.P	- PROCESSOR DEVICE	V = Vendor Specific
.W	- WRITE ONCE READ MULTIPLE DEVICE	R = Reserved
.R	- READ ONLY (CD-ROM) DEVICE	
.S	- SCANNER DEVICE	

The Linux SCSI programming HOWTO

```
#include <string.h>
#include <fcntl.h>
#include <errno.h>
#include <scsi/sg.h>

#define SCSI_OFF sizeof(struct sg_header)
static unsigned char cmd[SCSI_OFF + 18];      /* SCSI command buffer */
int fd;                                       /* SCSI device/file descriptor */

/* process a complete scsi cmd. Use the generic scsi interface. */
static int handle_scsi_cmd(unsigned cmd_len,   /* command length */
                           unsigned in_size,  /* input data size */
                           unsigned char *i_buff, /* input buffer */
                           unsigned out_size, /* output data size */
                           unsigned char *o_buff /* output buffer */
                           )
{
    int status = 0;
    struct sg_header *sg_hd;

    /* safety checks */
    if (!cmd_len) return -1;                /* need a cmd_len != 0 */
    if (!i_buff) return -1;                /* need an input buffer != NULL */
#ifdef SG_BIG_BUFF
    if (SCSI_OFF + cmd_len + in_size > SG_BIG_BUFF) return -1;
    if (SCSI_OFF + out_size > SG_BIG_BUFF) return -1;
#else
    if (SCSI_OFF + cmd_len + in_size > 4096) return -1;
    if (SCSI_OFF + out_size > 4096) return -1;
#endif

    if (!o_buff) out_size = 0;

    /* generic scsi device header construction */
    sg_hd = (struct sg_header *) i_buff;
    sg_hd->reply_len = SCSI_OFF + out_size;
    sg_hd->twelve_byte = cmd_len == 12;
    sg_hd->result = 0;
#ifdef 0
    sg_hd->pack_len = SCSI_OFF + cmd_len + in_size; /* not necessary */
    sg_hd->pack_id; /* not used */
    sg_hd->other_flags; /* not used */
#endif

    /* send command */
    status = write( fd, i_buff, SCSI_OFF + cmd_len + in_size );
    if ( status < 0 || status != SCSI_OFF + cmd_len + in_size ||
        sg_hd->result ) {
        /* some error happened */
        fprintf( stderr, "write(generic) result = 0x%x cmd = 0x%x\n",
                sg_hd->result, i_buff[SCSI_OFF] );
        perror("");
        return status;
    }

    if (!o_buff) o_buff = i_buff;          /* buffer pointer check */

    /* retrieve result */
    status = read( fd, o_buff, SCSI_OFF + out_size);
    if ( status < 0 || status != SCSI_OFF + out_size || sg_hd->result ) {
        /* some error happened */
        fprintf( stderr, "read(generic) result = 0x%x cmd = 0x%x\n",

```

The Linux SCSI programming HOWTO

```

        sg_hd->result, o_buff[SCSI_OFF] );
    fprintf( stderr, "read(generic) sense "
        "%x %x %x\n",
        sg_hd->sense_buffer[0],          sg_hd->sense_buffer[1],
        sg_hd->sense_buffer[2],          sg_hd->sense_buffer[3],
        sg_hd->sense_buffer[4],          sg_hd->sense_buffer[5],
        sg_hd->sense_buffer[6],          sg_hd->sense_buffer[7],
        sg_hd->sense_buffer[8],          sg_hd->sense_buffer[9],
        sg_hd->sense_buffer[10],         sg_hd->sense_buffer[11],
        sg_hd->sense_buffer[12],         sg_hd->sense_buffer[13],
        sg_hd->sense_buffer[14],         sg_hd->sense_buffer[15]);
    if (status < 0)
        perror("");
}
/* Look if we got what we expected to get */
if (status == SCSI_OFF + out_size) status = 0; /* got them all */

return status; /* 0 means no error */
}

#define INQUIRY_CMD      0x12
#define INQUIRY_CMDLEN  6
#define INQUIRY_REPLY_LEN 96
#define INQUIRY_VENDOR  8      /* Offset in reply data to vendor name */

/* request vendor brand and model */
static unsigned char *Inquiry ( void )
{
    unsigned char Inqbuffer[ SCSI_OFF + INQUIRY_REPLY_LEN ];
    unsigned char cmdblk [ INQUIRY_CMDLEN ] =
        { INQUIRY_CMD, /* command */
          0, /* lun/reserved */
          0, /* page code */
          0, /* reserved */
          INQUIRY_REPLY_LEN, /* allocation length */
          0 }; /* reserved/flag/link */

    memcpy( cmd + SCSI_OFF, cmdblk, sizeof(cmdblk) );

    /*
     * +-----+
     * | struct sg_header | <- cmd
     * +-----+
     * | copy of cmdblk   | <- cmd + SCSI_OFF
     * +-----+
     */

    if (handle_scsi_cmd(sizeof(cmdblk), 0, cmd,
        sizeof(Inqbuffer) - SCSI_OFF, Inqbuffer )) {
        fprintf( stderr, "Inquiry failed\n" );
        exit(2);
    }
    return (Inqbuffer + SCSI_OFF);
}

#define TESTUNITREADY_CMD 0
#define TESTUNITREADY_CMDLEN 6

#define ADD_SENSECODE 12
#define ADD_SC_QUALIFIER 13
#define NO_MEDIA_SC 0x3a
#define NO_MEDIA_SCQ 0x00

```

The Linux SCSI programming HOWTO

```
int TestForMedium ( void )
{
    /* request READY status */
    static unsigned char cmdblk [TESTUNITREADY_CMDLEN] = {
        TESTUNITREADY_CMD, /* command */
        0, /* lun/reserved */
        0, /* reserved */
        0, /* reserved */
        0, /* reserved */
        0}; /* reserved */

    memcpy( cmd + SCSI_OFF, cmdblk, sizeof(cmdblk) );

    /*
     * +-----+
     * | struct sg_header | <- cmd
     * +-----+
     * | copy of cmdblk   | <- cmd + SCSI_OFF
     * +-----+
     */

    if (handle_scsi_cmd(sizeof(cmdblk), 0, cmd,
                       0, NULL)) {
        fprintf (stderr, "Test unit ready failed\n");
        exit(2);
    }

    return
        *((struct sg_header*)cmd)->sense_buffer +ADD_SENSECODE) !=
        NO_MEDIA_SC ||
        *((struct sg_header*)cmd)->sense_buffer +ADD_SC_QUALIFIER) !=
        NO_MEDIA_SCQ;
}

void main( void )
{
    fd = open(DEVICE, O_RDWR);
    if (fd < 0) {
        fprintf( stderr, "Need read/write permissions for "DEVICE".\n" );
        exit(1);
    }

    /* print some fields of the Inquiry result */
    printf( "%s\n", Inquiry() + INQUIRY_VENDOR );

    /* look if medium is loaded */
    if (!TestForMedium()) {
        printf("device is unloaded\n");
    } else {
        printf("device is loaded\n");
    }
}
}
```
